



RESET




POWER



P13




PWR



Pitftduino - V07p

www.zaboco.atervista.org



V0-A2



TXD  
RXD  
GND  
2V



2V  
GND  
ZCK  
MOZI  
MIZO  
R2T



DTR



05\5012

BTFBTHC02

q2B - v2b